

# FOOTPADS AND STRAPS V2

## HOW TO SET UP AND ADJUST



1:: UNDO THE STRAP VELCRO AND REMOVE THE TONGUES.



2:: SLIDE THE STRAP TONGUES UP THROUGH THE FOOTPAD BASEPLATE SLOT FROM THE UNDERSIDE


MAKE SURE THE TONGUE ANGLE FACES FORWARD, TOWARDS THE TOE SIDE OF THE FOOTPAD.  
**NOTE:** THERE IS NO LEFT OR RIGHT TONGUE, ALL TONGUES ARE THE SAME.



**3::** FEED THE VELCRO STRAPS THROUGH THE TONGUE SLOT WHILE INSERTING THE TONGUES INTO THE STRAP ON EACH SIDE.



THE TOP VELCRO STRAP END FACES TOWARDS THE CENTRE OF THE BOARD.



**4::** POSITION THE STRAP TONGUES AT THE MIDDLE BASEPLATE SETTING. THIS IS THE STANDARD POSITION.



**5::** LINE UP THE BASEPLATE HOLES WITH THE BOARD INSERTS AND FASTEN THE SCREWS.



YOU CAN CHOOSE BETWEEN FIVE STANCE ANGLES, THE CENTRE HOLE IS THE STANDARD POSITION.



**6::** WITH THE SCREWS TIGHTENED DOWN, PUT YOUR FOOT IN THE STRAP AND ADJUST THE VELCRO LEFT AND RIGHT SIDES TO FIT.



⚙️ AFTER FIRST USE AND PERIODICALLY WE RECOMMEND TO CHECK ALL SCREWS AND RE-TIGHTEN IF NECESSARY.



**STANDARD TONGUE POSITION**



**SLIDE TONGUE BACKWARDS**



**SLIDE TONGUE FORWARDS**

7⚙️ FOR A FURTHER CUSTOMISED FIT YOU CAN TRY THE VARIOUS STRAP POSITIONS USING THE TONGUE AND BASEPLATE SLOT.

SLOWLY UNDO THE BASEPLATE SCREWS (DON'T UNSCREW ALL THE WAY) TO ALLOW CLEARANCE FOR THE STRAP TONGUE TO BE PUSHED DOWN, THEN MOVE THE TONGUE FORWARD OR BACKWARD IN THE BASEPLATE SLOT, THEN PULL IT BACK UP INTO PLACE.

EACH STRAP TONGUE HAS THREE POSITIONS IN THE BASEPLATE, WHICH ALLOWS FOR NINE DIFFERENT STRAP POSITIONS WHEN COMBINING LEFT AND RIGHT TONGUE POSITIONS. ONCE YOU FIND THE BEST SETTING TIGHTEN THE BASEPLATE SCREWS BACK DOWN.